

RU-4 Terminal Electrolytic Recovery

Application Range: 1.5 to 2 gallons per day (24 hours).

Typical Silver Discharge: 0.75 PPM to 3 PPM

Application Notes:

- Replace RePAC 10 cartridge every 300 gallons processed, or every 6 months.
- Replace Vault I cartridge every 200 gallons, or every 6 months.
- Limit collection of silver on the cathode to 4-6 pounds (1/4 inch thick).
- Clean out CT-5 tank and overflow fittings every 6 months.

Typical Installation:

