

METS™ A-101 & E-112

Environmental Treatment Systems for Reducing Silver Discharge

Mini Environmental Treatment Systems (METS) provide the simplest solution for environmental compliance.

CPAC's METS systems are designed to help mini, micro, and small professional photo labs meet tough environmental compliance regulations.

With their unique metering pump/collection tank design, METS are built to maximize silver recovery cartridge performance while reducing silver discharge to less than 1ppm.

Features & Benefits

- Simple to operate
- Maintenance-free
- Quick installation
- Universal bleach-fix & fixer compatibility
- Compact design
- Standard safety features
- Built-in 110% secondary containment



www.cpacequipment.com

METS™ Features & Product Data

METS units can treat all combinations of fix and bleach-fix, up to 144 liters per day. Solution can be plumbed directly into the METS unit, or poured via its hinged cover. All METS units feature an adjustable precalibrated metering pump, and corrosion-resistant tanks, trays, and fittings. Safety features include an automatic pressure relief mechanism designed into the pump assembly, low voltage operated liquid level switches, and circuit breakers.

The METS effluent treatment systems are designed for use with RePAC® 250 cartridges. To achieve optimum performance, CPAC recommends these cartridges. Contact CPAC at **800-828-6011** for additional information.

METS E-112

- Built-in 110% secondary containment for collection tank and cartridges
- Audible overflow alarm
- Reusable filter system
- Adjustable metering pump (50-125 ml/min)
- Quick disconnect fittings
- Pressure relief valve
- Easy to remove components make cleaning simple

Construction

- Leak-proof, one-piece polyethylene collection tank and containment tray
- Easy-roll casters

Dimensions & Weight

24"W x 21.5"L x 26.75"H 65 lbs. (29.5 kg)

Electrical

115 Volt (150 VA), 50/60 Hz

230 Volt (150 VA), 50/60 Hz models available

METS A-101

- Built-in 110% secondary containment for collection tank and cartridges
- Programmable gallon counter
- Resettable external hours counter (0.1-999.9 hours)
- Adjustable metering feed pump (0-125 ml/min)
- Battery back-up
- 7.5 gallon capacity
- 'Pump-on' indicator
- Quick disconnect fittings
- Pressure relief valve
- Solid-state electronics
- Easy to remove components make cleaning simple

Construction

- Leak-proof, one-piece polyethylene collection tank
- Polypropylene cabinet
- Easy-roll casters

Dimensions & Weight

22.5"W x 20"D x 27.25"H 65 lbs. (29.5 kg)

Electrical

115 Volt (150 VA), 50/60 Hz

230 Volt (150 VA), 50/60 Hz models available

cpac, inc.

PHONE (585) 382-3223

FAX (585) 382-9481