



- **3 solutions per machine**
- **Lowest ever cost**
- **Completely automatic**
- **Failsafe**
- **Simple to use and calibrate**
- **Improved accuracy**
- **Constant supply of fresh chemistry**

Due to the growing demand for higher quality images at the best price the MicroMixer has been redesigned making it more cost effective. The unit can house a maximum of three solutions per cabinet and operates using purpose designed electronics and software.

The easy to follow menu driven calibration routine guides you through the setup of the mixer, making it possible for the user to commission the machine. The unit is floor standing and is very compact so it can be installed in the tightest of spaces in less than 2 hours.

The unit can mix up to 3 different solutions of up to 3 chemical parts and water and has been optimized to make it cost effective even when single part homogenous chemistries are used. A new MicroMixer LE RA4/C41 costs 30% less than the older standard MicroMixer.

The mixer has all the benefits of our larger models, failsafe, accurate, safe to leave unattended and requires minimal user intervention.

**Services:**

115-240VAC 50/60 cycles 225VA

Requires tempered water at mixing temperature, consumption 2 litres per minute.

Dimensions: 500x 890 x 300 (L x H x W)

For more information contact Rockwell Hitec.

**Manufactured By:**

Rockwell Hitec Ltd, 6 Alpha Business Park,  
Travellers Close, Welham Green, Hatfield  
Hertfordshire, AL9 7NT England  
Tel: (01707)-269086 Fax: (01707)-269099

**Distributed By:**

CPAC Imaging  
2364 Leicester Road  
Leicester, NY 14481  
Tel: (585) 382-3223 Fax: (585) 382-9481