

Black & White Film Process

For B&W Film Processing

Trepan 1200T Developer

This D-76 type film developer is used to prepare a working solution in a continuous processor, tray or rotary tube process. Trepan 1200T one-part liquid concentrate dissolves instantly and eliminates the mess of powder chemicals - simply mix with water. The tank solution of a continuous processor is replenished with Trepan 1200R Developer Replenisher.

Cat. Number	Mix Size	Shipping Weight
40DE405	1 x 25 G	57 lbs. 25.8 kg

Specifications:
Time: 1'50" - 6'30"
Temperature: 65° - 77° F (18° - 25° C)

Replenishment Rate*: NA

Trepan RT Film Developer

This "universal" black-and-white film developer is a two-part liquid concentrate that makes 20 gallons. It is well suited for processing T-max film as well as Plus-X and Tri-X films. Its integral hardener minimizes film scratching. Trepan RT Black & White Film Developer is compatible with both roller transport and cine machines. Not recommended for rack-and-tank or small tank processing. Requires starter RT Developer Starter.

Cat. Number	Mix Size	Shipping Weight
40DE415	1 x 20 G - Part A	56 lbs. 25.5 kg
40DE416	1 x 20 G - Part B	52 lbs. 23.6 kg

Specifications:
Time: Variable
Temperature: 65° - 80° F (18° - 27° C)

Replenishment Rate*: 29 ml/ft² 312 ml/m²

Trepan RT Developer Starter

Trepan RT Developer Starter is designed specifically to make new working solution from Trepan RT replenisher.

Cat. Number	Mix Size	Shipping Weight
40DE418	6 x 1 quart - Starter	18 lbs. 8.2 kg
40DE418S	1 x 1 quart - Starter	3 lbs. 1.4 kg

Trepan 1200R Developer

Trepan 1200R is a one-part liquid concentrate D-76 type film developer used only as a replenisher. Trepan formulas produce excellent results with most films. Time, temperature and replenishment rates are adjustable for almost any black-and-white processor.

Cat. Number	Mix Size	Shipping Weight
40DE406	1 x 20 G	55 lbs. 25 kg

Specifications:
Time: Variable
Temperature: 68° - 77° F (18° - 25° C)

Replenishment Rate*: 40 ml/ft² 430 ml/m²

Trepan Rapid Fixer

Trepan Rapid Fixer is a one-part, liquid concentrate that produces clear, high quality negatives. Combined with Trepan Rapid Fixer Hardener, it delivers the best possible scratch protection for film. When mixed 1:8 with water (without hardener), it can be used as a black-and-white paper fixer.

Cat. Number	Mix Size	Shipping Weight
40FX408	1x 20 G	56 lbs. 25.3 kg

Specifications:
Time: 3'00" - 10'00"
Temperature: 65° - 80° F (18° - 27° C)

Replenishment Rate*: 30 ml/ft² 323 ml/m²

Trepan Rapid Fixer Hardener

This liquid concentrate is used with Trepan Rapid Fixer to provide the best film scratch protection available. Convenient, easy-to-handle packaging.

Cat. Number	Mix Size	Shipping Weight
40FX409	6 x 20 G	29 lbs. 13.1 kg