

# Black & WhitePAC Kit

For B&W Film & Paper Processing

## Black & WhitePAC Kit Film Products

Trebla's **Black & WhitePac Kit** contains pre-measured amounts of Black & White concentrates to process 25 rolls of 135mm/36 exposure film and 140 sheets of 8x10 paper. The kit is for any lab that requires small amounts of chemistry for black & white paper (tray processing) and film (rack and tank processing). Everything you need to process paper and film is conveniently packaged in one box.

The **Trepan 1200T Film Developer** is a D-76 type film developer used to prepare a working tank solution in a tray or rotary tube process. The liquid concentrate eliminates the mess and measuring of powder chemicals—simply mix with water.

The **Trepan Rapid Fixer with Hardener for Film** is a liquid concentrate that produces clear high quality negatives. A bottle of Trepan Rapid Fixer Hardener is included to deliver the best possible scratch protection for the film.

## Black & WhitePAC Kit Paper Products

The **Trepan 2000 Paper Developer** produces a cool, technical-looking black that gives a rich tone to the finished prints. This clean-running, easy-to-use liquid concentrate resists oxidation, and operates consistently—no matter what the usage. Trepan 2000 Paper Developer is designed for use in tray and rotary tube processing.

The **Trepan Rapid Fixer For Paper** is used to complement the Trepan 2000 Developer and Replenisher. Its non-hardening formula is pH buffered so no stop bath is required. Trepan Rapid Fixer delivers consistent performance, even under less than ideal conditions.

Catalog Number	Packaging	Shipping Weight
40BW420	5 L Trepan 1200T Film Developer	30 lbs.
	5 L Trepan Rapid Fixer with Hardener for Film	
	5 L Trepan 2000 Paper Developer	
	5 L Trepan Rapid Fixer for Paper	

***Processing specifications for time, temperature and replenishment are included in the Black & WhitePAC Kit.***