

# Duster

**1000 S** (Standard)

**1000 FC** (Fume Control)

Engineered to remove:

- Dust
  - Odors
  - Smoke
  - VOCs
  - Mists
  - Spray Powder
  - Toxic Fumes
  - Pollen and Bacteria
- *Clean shop air up to 1,000 sq. ft.*
  - *Floor level pick-up, circulates all the air*
  - *Lightweight and mobile*
  - *Operates on standard 110 volts*
  - *No assembly required – ready to use*
  - *Quiet operation, Ø to 68db*
  - *Cleanable intake filters*
  - *Meets OSHA and EPA requirements*
  - *5 Year warranty*



## Specifications

<b>ELECTRICAL:</b>	1/2 HP, 1.0–10 Amp 110V Direct Drive Motor Variable speed control
<b>BLOWER CAPACITY:</b>	1000 CFM
<b>FILTER MONITOR:</b>	Digital Readout
<b>CONSTRUCTION:</b>	Molded polyethylene, Impact resistant
<b>WEIGHT:</b>	71 lbs (standard) 32 kg
<b>NOISE LEVEL:</b>	Ø to 68 db
<b>WARRANTY:</b>	5 years parts, excluding filters

**FILTERS:** Made in the USA and Canada.

	Part #	Qty
<b>1. DUST PAD</b> 16" x 16" x 2" (406mm x 406mm x 50mm)	11706	2
<b>2. INTAKE FILTER</b> 16" x 16" x 4" – 60 pleats (406mm x 406mm x 100mm)	11202	2
<b>3. CARBON FILTER (refillable)</b> Standard 16" x 16" x 1-1/2" – 7lbs 406mm x 406mm x 38mm – 3.2 kg or Fume Control 16" x 16" x 3" – 14.5 lbs 406mm x 406mm x 76mm – 6.6 kg	11208 11303	2 2

Specifications subject to change without notice

Marketed by



2364 Leicester Road, P.O. Box 175  
Leicester, New York 14481  
www.cpacimaging.com

Phone (585) 382-3223  
(800) 828-6011  
Fax (585) 382-9481

Manufactured in Canada by



**AIRFLOW DIRECTION**



Particle Type	Microns
Duster Intake filters	1.0
Diameter of human hair	50.0 - 100.00
Dust becomes visible	Over 18.0
Viruses	Over 0.04

**STANDARD FILTERS**

**11208  
CARBON FILTER  
(Refillable)**

Removes fumes and odors.  
Contains 7lbs (3.2 kg) of activated pellets carbon.  
Not cleanable.  
2 per unit



**FC Model  
11303  
CARBON FILTER  
(Refillable)**

Contains 15 lbs (6.8 kg) of activated carbon pellets.  
Not cleanable  
2 per unit



**11202  
INTAKE FILTER**

Surface loading media to capture pollutants to 1 micron. Pleated high surface area (26 sq ft), metal frame, (11706 pad in front).  
Vacuum cleanable  
Pressure washable  
2 per unit



**11706  
DUST PAD**

High capacity media to capture visible dust and spray powder.  
Used in front of intake filter  
Vacuum cleanable  
2 per unit

Distributed by: